### **LINEA Instructions of assembly**



#### LINEA Instructions of assembly

#### **Tool Needed**

- 1.Tape measure(Max 3 Metre)
- 2.Spirit level
- 3.Cross head Screw driver
- 4.Electric drill
- 5.Hammer



## STEP 1)

Mark the distance with pencil on the wall as the drawing shows.

Then drill holes on the wall with Electric drill.



STEP 2) Fix aluminium alloy hanger onto the wall.



#### STEP 3)

Make sure the yellow expansion pipe and the expansion bolt is fixed from the cabinet back panel to the wall.



## STEP 4) Hang cabinet unit on the wall and adjust perfectly



# STEP 5)

Put the basin or worktop on the cabinet. Add with silicon.

